



MIRACLE

FRY OIL FILTER POWDER™ Dosage and Instructions

www.acefilters.com.au

MIRACLE FILTER POWDER

works by removing food debris and impurities from your fryer oil which are a major cause of oil breakdown. By using MIRACLE FILTER POWDER daily you can increase the life of your oil by up to 60% which means more profit for you! Your oil will stay cleaner day after day and you will serve maximum quality fried food from your clear odour-free fryer oil





Dump Day





OIL FILTERED DAILY USING MIRACLE




ACE FILTERS AUSTRALASIA

9 Eastspur Court, Kilsyth Vic. 3137

Tel: (03) 9761 4920 Fax: (03) 9761 6127 Email: enquiries@acefilters.com.au

Web: www.acefilters.com.au





POWDER TO FRY OIL RATIO (DOSAGE)

25 litre Vat Capacity	Filter Media	Powder dosage (grams)
Powder dosage depends on the filter	Paper	100> 135
media used in your filter machine	Polyester	200> 250

This chart above represents average fryer loadings cooking fries & fish for a medium trading business. For restaurants with greater fryer loading we recommend the heavier dosage levels as above to avoid the excessive build-up of FFA, OFA and carbon matter.



This is an example of 90grams of pure FFA produced daily from 25 litres of used frying oil which Miracle Powder will absorb



Miracle Powder is available in packets or in a 20kg bulk bag.

A regular sized drink cup holds 135 grams of powder

A medium sized drink cup holds 250 grams of powder

4 Easy Steps to Super Clean Oil



Wheel-up Filtering Machines



 Miracle Filter Powder can be simply cast into the oil or spread evenly over the filter paper Add the required dosage of MIRACLE to fryer while oil is at working temperature



2. Drain oil from fryer into filter machine.



3. Start filter machine and hose inside of fryer. Allow oil in filter machine to recirculate (polish) by hanging outlet hose over the fryer and allowing the oil to run back into the filter machine for a minimum of 5 minutes.



4. After polishing your oil close fryer outlet and pump clean MIRACLE Oil back into the fryer. Switch fryer on and allow to come to working temperature